


DPA RF Quick Start Guide



1



7



Instructions:

- 1 Install RP1210-compliant PC drivers from the CD. The latest RP1210-compliant PC drivers can always be found at <http://www.dgtech.com>.
- 2 Attach antenna and vehicle cable to DPA RF Remote Station.
- 3 Connect the DPA RF Remote Station to the vehicle.
- 4 Attach antenna and DB9 serial cable to DPA RF Base Station.
- 5 Attach DB9 serial cable to PC.
- 6 Connect the AC power supply to the DPA RF Base Station. Then connect to 110 Volt outlet.
- 7 Configure your RP1210-compliant diagnostic application to use the DPA RF. The "DPA User Manual" contains information for configuring many of the "common" applications. If your application is not covered in the manual, consult the documentation that came with your application on how to configure for RP1210-compliant adapters.