

DPA 4 Plus Quick Start Guide



1




4


2




2



2



3



Instructions:

- 1 Install RP1210-compliant PC drivers from the CD.
The latest RP1210-compliant PC Drivers can always be found at <http://www.dgtech.com>.
- 2 Connect the vehicle cable and USB cable to the DPA and then to the PC.
- 3 Connect the DPA to the vehicle diagnostic port.
- 4 Configure your RP1210-compliant diagnostic application to use the DPA. The "DPA User Manual" contains information for configuring many of the "common" applications. If your application is not covered in the manual, consult the documentation that came with your application on how to configure for RP1210-compliant adapters.